



NOTE:
 REFER TO EAVE & RIDGE DETAILS FOR FURTHER INFORMATION ON PROPER PANEL TERMINATIONS.



DESIGN SPAN HP



SLOPE TRANSITION

DS-18