


FIELD NOTCH CAP AND BEND OVER TO CLOSE OFF END OF BATTEN CAP.

PULL SIDES IN AND INSTALL 1/8" RIVET FROM EACH SIDE



BATTEN CLIP AND PANEL CLIP REFER TO PANEL CLIP DETAIL FOR INSTALLATION

BATTEN CAP

DESIGN SPAN HP PANEL

SPECIFIED UNDERLAYMENT (NOT BY AEP-SPAN)

PANCAKE HEAD FASTENER 12" O.C.

3/16"x7/8" BUTYL TAPE

3/8" BEAD OF NON-SKINNING BUTYL SEALANT ON BOTH SIDES OF MALE RIB

1/8" RIVETS IN SEALANT LINE IF NECESSARY TO CLOSE "FISHMOUTH"

EAVE TRIM 3" (ET041) 4" (ET043)

JOGGLE CLEAT (JC095)

PANCAKE HEAD FASTENER 12" O.C.

TRIM CLEAT (TC209)



DESIGN SPAN HP



EAVE (WIDE BATTEN)

DS-06