



NOTE: PANELS MUST BE HAND CRIMPED TO 90° AT ALL CLIPS BEFORE MECHANICALLY SEAMING PANELS. ONLY USE HAND CRIMPING TOOLS DESIGNED FOR THE SPAN-LOK PANELS.



SPANSEAM



CLIP &
THERMAL SPACER

SPS-28