



NOTE:
PANELS MUST BE HAND CRIMPED AT
CLIPS BEFORE MECHANICALLY SEAMING
PANELS. USE HAND CRIMPING TOOL
DESIGNED FOR THE SPAN-LOK/SPANSEAM
PANEL.



SPANSEAM



CLIP &
THERMAL SPACER

SPS3D2