


**INSTALLATION NOTES:**

- ZEE CLOSURE MUST BE CONTINUOUS AND BE NOTCHED FOR PANEL RIBS.
- BATTEN MUST STOP AT OUTSIDE FACE OF ZEE CLOSURE AND NOT PASS THROUGH.



**SELECT SEAM**  
WIDE BATTEN



HEAD WALL

SSWB-09